



Grundfos sensors for gas boilers

Differential Pressure Sensor (DPS). Test kit for demonstration purposes.



TM03 1915 3305


Electrical connections:




Pin configuration :

- 1 Temperature signal (0.5 ... 3.5 V relative to pin 3)
- 2: Pressure signal (0.5 ... 3.5 V relative to pin 3)
- 3: Ground (0 V)
- 4: Supply + (5 V dc)

TM03 0105 3305




TM03 0104 3305



TM03 0103 3305

Electrical connection to the boiler system:



Kit no.	Part no.	Max. pressure [bar]
96629726	96605148	0.6

TM03 0102 3305

DISCLAIMER OF WARRANTY

The sensor is a prototype sensor(*) not released for sale. The final testing of the prototype sensor has not been completed.

This prototype sensor is intended for development engineers who wish to demonstrate, evaluate and test the sensor.

Although the prototype has been designed and assembled carefully by Grundfos, Grundfos makes no warranties, expressed or implied, that the prototype sensor(*) is free of errors, meets any specifications or test criteria's, or that it will meet the requirements of any particular application. In particular, we point out that the prototype sensor(*) is not verified for use with or works together with any other Grundfos products.

The prototype sensor should only be used by persons trained for performing relevant demonstrations, evaluations and tests in a manner which is safe and in accordance with any local legislation. The prototype sensor should only be used in a safe and closed environment, and hence should not be relied on in any situation where an incorrect sensor reading, a leakage, fracture or breakdown in the prototype sensor, an electromagnetic disturbance from the prototype sensor to the environment or from the environment to the prototype sensor, or any other malfunction in the prototype sensor or in its interface with other system components, can cause injury to a person or loss of property.

Grundfos disclaims all liability for direct, indirect, incidental, or consequential damages resulting from use of the prototype sensor. Any liability of Grundfos is limited to replacement of the prototype sensor.

The prototype sensor may not be passed on to or otherwise utilized by any third party without Grundfos' expressed written permission. The prototype sensor may under no circumstances be the subject of sale or resale in itself or as part of a system.

This disclaimer applies to any sensor with part number 96629726 or 96605148 supplied by Grundfos independently of time of delivery unless a written agreement of delivery has been established between Grundfos and the customer, in which other terms of warranty are explicitly defined.

(*) Prototype sensor means the prototype sensor itself plus any accessory or fittings such as but not limited to O-rings, clips, pipe sections, cables, adaptors or documentation.

96643091 0906	GB

Subject to alterations.